


Tenob Replacement Bung Sizing



Measuring Instructions

Bungs are sized to the actual hole size in the base. The measurement to the outside of the thread will be bigger than the hole size.

To select correctly use the measurement at **A**. It should be different to measurement **B** which is outside the threads.

To help you recognise and order the correct bung, the available replacement ones are shown below with their **A** dimension.



BU27 - 19mm
Chrome



BU32 - 31mm



BU37 - 31mm



BU42 - 18mm



BU47 - 18mm



BU52 - 19mm fine thread



BU52W - 19mm fine thread



BU62 - 16mm



BU295 - 16mm



BU302 - 21mm



BU307 - 21mm



BU392 - 40mm



BU397 - 40mm



BU29 - 19mm
Stainless Steel

Click on your selected bung and you will be taken to the correct section of the Tenob website.



241 Ti Rakau Drive,
Burswood,
Auckland
Ph: 0800 2739180